Switch-On | Switch-Off

ser Percautions
ser read these simple guidelines. Not following them may be dangerous or illegal. For further information, see the section of «Warnings and Precautions» in complete manuel delivered in the attached CDROM.

Not switch the phone on when Mobile Phone use is prohibited or when it may cause interference or danger.

To place your phone and its accessories in containers with strong electromagnetic field.

y all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.

pitals or health care facilities may be using equipment that could be sensitive to external radio frequency energy. Follow any regulations or rules in force.

not use the phone at a refueling point. Do not use near fuel or chemicals.

way ney restrictions. Wireless devices can cause interference in aircraft.

p the phone and all its parts, including accessories, out of the reach of small children.

only approved batteries and chargers. Disconnect the charger from the power source when it is not in use. Do not leave the battery connected to a charger for e than a week, since overcharging may shorten its life.

y applicable to the device.

FCC Warning
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two Conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any Interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio fre quency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.









Special events





SOS












Emergency call











Prepare









Action of blue key → Select

Repeat (TTS)

Loud

─ | Quiet

Mute (TTS) (3 sec.



Reception level → Y.III ◄× IIII ← Battery Level

Call log

Contacts



Upper item 📥 Pointed item **OK**

Lower item **▼**

Ear-Set connector

 $\dashv ^{f \psi}$ USB connector

Back ← Action of red key



Starting










Your ALTO II Mobile Phone Overview





Keys and keyboard in

List of shortcuts

Erase a call log entry or single SMS = # Create contact from received Call or SMS = 0 Hands-free = press Call (GREEN) button during active call Indication of the battery level =*#01# Indication of the signal strength =*#02# Indication of Date and Time = *#03# Indication of the name of Operator = *#04# Delete all entries of the Inbox =*#10# Delete all entries of the Outbox =*#11# Restore factory settings = ***#7378673#**







Answer a call

Call a contact



Call a number







